

ALADDIN[®]


Model 21c Kerosene Lamp Burner

Exploded View Parts List


Lighting The World, Since 1908

Sold from 1955 to 1963

Model 21c Wick Raiser
(No longer Available.
See note below.)




NOTE: Use N233 Model 23
Wick Raiser with N230 #23
Wick to replace the parts to
restore a Model 21c burner.



R199 Model 21 Wick
fits Models 21 & 21c
lamp burners.

*R199 No Longer Available
(See Above)*

Aladdin Lox-On
Chimney is 12 1/2
inches tall with
2 5/8 inches
bottom fitter.




R103 Lox-On
Chimney fits
Models 12, A, B, C,
14-English, 21, 21c
and 23 lamp
burners.


Enlarged view of Model 21c
wick raiser knob.

Note: When ordering parts
for your Aladdin, always
provide your burner model
number.

R150 Lox-On Mantle
fits Models 12, A, B, C,
14-English, 21, 21c, 23
and 23A lamp burners.




N239 Burner Gallery
fits Models 21, 21c, 23
and 23A, when using a
R103 Lox-On chimney.




N106 Flame Spreader
fits Models 12, A, B, C,
14-English, 21, 21c, 23,
23A lamp burners and
23E60 fridge burner.



N238 Outer Wick Tube
fits Models 21, 21c, 23,
23A lamp burners and
23E60 fridge burner.



Model 21 Burner Base
(Not Sold Separately)



R111 Wick Trimmer
fits all one inch Aladdin
kerosene lamp burners



Crownplace Brands
291 Kurzen Road North
Dalton, OH 44618 USA
Phone: (888) 332-5534 Fax: (815) 572-8518
Website: www.aladdinlamps.com
Email: info@crownplacebrands.com

